










 <p>(A)</p> <p>x2</p>	 <p>(E)</p> <p>x20</p>	 <p>(I)</p> <p>x2</p>
 <p>(B)</p> <p>x1</p>	 <p>(F)</p> <p>x12</p>	 <p>(J)</p> <p>x20</p>
 <p>(C)</p> <p>x4</p>	 <p>(G)</p> <p>x4</p>	 <p>(K)</p> <p>x20</p>
 <p>(D)</p> <p>x1</p>	 <p>(H)</p> <p>x2</p>	



**Problems? Please do not return to store or catalog company. For assistance with assembly or missing parts, call 1-800-771-0529 (outside USA call 904-482-0091) from 9am to 5pm EST or email: [parts@advantus.com](mailto:parts@advantus.com)**