

## L355MB PL 18W Lamp

Important instructions pertaining to risk of fire, electric shock or injury are contained.

**WARNING – Lighted lamp is HOT.**

To reduce the risk of **FIRE, ELECTRIC SHOCK OR INJURY TO PERSONS:**

- ~Turn off/unplug and allow lamp to cool before replacing bulb, cleaning or other maintenance.
- ~Do not touch hot/warm bulb at any time.
- ~Do not look directly at lighted bulb.
- ~Keep lamp away from materials that may burn.
- ~Bulb and shade can get **HOT!** Touch only the switch/plug when turning on.
- ~Use a **PL 18 Watt Fluorescent Bulb.**

### Assembly Instructions

1. Take the lamp and clip out of the package and lay them on a smooth surface. Remove any packing material.
2. Adjust the stem and shade of lamp to desired positions.
3. Lock screw and adjust arm.
4. Plug in the lamp and turn on the switch.

### Bulb Replacement

1. Switch off and unplug the lamp. Allow the bulb to cool completely before replacing.
2. Remove the rubber band from the locking clips that hold the bulb in place.
3. Remove the old bulb and replace it with a new one according to the bulb caution label applied on the shade.
4. Replace the rubber band and make sure it is securely in place.

### Maintenance

1. Use only a **PL 18 Watt Fluorescent Bulb**
2. Use only a soft cloth to clean.
3. Do not use any chemical or abrasive cleaners on any part of the lamp.

### Important Safety Instructions

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter plug.

