

ITEM NO: L9074 INSTRUCTIONS

BULB REPLACEMENT INSTRUCTIONS:

1. Take out two screws with screw driver and remove lens from screen.
2. Push halogen bulb to the side as shown in (2A) and take out damaged bulb as shown in (2B).
3. take new halogen bulb and push to the side as arrow A shows.
Then install other end of bulb in to socket.
4. Put the lens back with two lens holders and tighten the screw to secure the lens in place.
5. Use 120v 150w(maximum) type T double-ended halogen bulb(bulb included).

Caution:

1. Please be sure to turn off the power and wait until the bulb has cooled down before replacing the bulb and cleaning the lamp.
2. Please do not look directly at the lit bulb.
3. This unit comes with a protective glass shield which protects against ultraviolet radiation. User should take caution in replacing these protective glass shields after either installation or replacement of tungsten halogen lamp.

Important safety instructions(FOR USA&CANADA VERSION ONLY):

This portable lamp has a polarized plug(one blade is wider than the other)as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

**PLEASE INFORM YOUR DEALER IMMEDIATELY
IN CASE OF ANY PARTS SHORTAGE.
SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.**

