

ITEM NO: L9088 INSTRUCTIONS

WARNING - Lighted lamp is hot!

To reduce the risk of FIRE, ELECTRIC SHOCK OR INJURY TO PERSONS:

- ~ Turn off/unplug and allow lamp to cool before replacing bulb, cleaning or other maintenance.
- ~ Do not touch hot/warm bulb at any time.
- ~ Do not look directly at lighted bulb.
- ~ Keep lamp away from materials that may burn.
- ~ Bulb and shade can get HOT! Touch only the switch/plug when turning on.
- ~ Use only with a 60 Watt or smaller bulb.




Assembly Instructions

- 1) Carefully unpack, remove all protective packing materials, and lay out all parts on a smooth surface.
- 2) Screw shade (A) into (B).
- 5) Screw in one 60 Watt Type A (not included) into socket.
- 6) Plug into outlet and use the rotary on/off switch to enjoy.

Maintenance

- 1) Use only a 60 Watt or smaller Type A light bulb.
- 2) To clean use a soft cloth only.
- 3) Do not use any chemical or abrasive cleaners.



WARNING: Illustration is for demonstration purposes only. Lamp should not be used with gooseneck fully extended. Shade should always be pointing in the same direction as the base. If the lamp is positioned differently it may tip over and cause damage.