

Cyberlegs

VF50139

Vertiflex
Products™

Assembly Instructions

www.advantus.com

904.482.0091

Assembly Overview




WARNING:

Attach arm assembly to computer only with materials enclosed to prevent possible damage to computer. Use care when removing arm assembly from computer. Hook and loop attachments are strong and may damage computer case if not separated with care.



- Matted hook and loop strip for mounting power source (Optional)
- Matted hook coins for mounting laptop
- No-skid rubber segments

Contents:



1

Use the template attached to this form to position the loop and hook coins on your computer and the Cyberlegs™ unit.





Loop side of strip holds 4 hook coins with no skid rubber. (Place hook coins over the loop coins on bottom of computer when arm assembly is removed)

Note: Hook and loop strips can be used to attach A/C transformer to front leg.

2

Connecting the Leg and Arm Assemblies

Open leg assembly to full span. Align arm assembly locking slot with locking post located on mounting head and turn clockwise to locked position.



Suggestion: Leave arm assembly attached to computer at all times. Unless using connecting computer to docking station.

