



Vertiflex™ Products

PORTABLE SOUND LECTERN
MODEL #590



5.
OPEN



SPEAKER


6.

INSTALL GOOSENECK
AND MICROPHONE CLAMP


MICROPHONE
CLAMP

TURN
CLOCKWISE

GOOSENECK




SQUEEZE
CLAMP



7.

INSTALL MICROPHONE



PLUG
MICROPHONE
CABLE INTO JACK
MARKED "MIC"

FOR ADDITIONAL
AMPLIFIER
SET-UP INFORMATION
SEE SEPARATE INSTRUCTIONS
PROVIDED WITH THAT
EQUIPMENT